MOTOR PROTECTION RELAY, PHASE FAILURE / SINGLE PHASE SENSITIVE. THREE POLE **Electric** (THREE PHASE), MANUAL OR AUTOMATIC RESETTING. DIRECT MOUNTING ON BF09 - BF38 **ENERGY AND AUTOMATION** CONTACTORS, 1.6...2.5A



Product designation			Motor protection relay
Product type designation			RF38
General characteristics			
Number of poles		nr.	3
Overvoltage category			III
Pollution degree			3
Frontal IP degree			IP20
Type of release			Thermal
Protection fuse			
	gG (IEC)	Α	6 A
	aM (IEC)	Α	4 A
	RK5 (UL)	Α	10 A
Phase failure detection			NO
Reset mode			Manual or
			automatic
Power circuit characteristics			
Operating frequency			
	Operational frequency max	Hz	400 1/s
Operating current			
	Operational current min	Α	1.6 A
	Operational current max	Α	2.5 A
Tripping class			10A
Test Button			YES
Trip indicator			YES
Terminals			
	type		Screw and
	typo		washer
	screw		M4
	tool		Phillips 2
Conductor section			
	AWG max		8
Auxiliary circuit characteristics			
Auxiliary contacts			
	NO	nr.	1
	NC	nr.	1
Operating current AC15			0.4
	24V	A	3 A
	120V	A	3 A
	240V	A	1.5 A
	380V	A	0.95 A
	480V	A	0.75 A
	500V	A	0.72 A
Operating current DC13	600V	A	0.6 A

M3,5

3000



ENERGY AND AUTOMATION

MOTOR PROTECTION RELAY, PHASE FAILURE / SINGLE PHASE SENSITIVE. THREE POLE **electric** (THREE PHASE), MANUAL OR AUTOMATIC RESETTING. DIRECT MOUNTING ON BF09 - BF38 CONTACTORS, 1.6...2.5A

Terminals	type		Screw and washer
Conventional free air thermal current Ith		Α	10 A
	600V	Α	0.22 A
	125V	Α	0.11 A

	tool	Phillips 2
UL/CSA and IEC/EN 60947-5-1 designation		B600-R300
Ambient conditions		

Max altitude Mechanical feautures

Operating position

	normal allowable		Vertical plan ±30°
Weight	(<u> </u>	0.16 kg
UL technical data			


Full-load current (FLA) for three-phase AC motor

at 480V Α 2.5 A at 600V Α 2.5 A


screw

Dimensions

BF00 A... BF09 A... - BF12 A... - BF18 A... - BF25 A... three poles with RF...38 thermal overload relay



- BF32 00A... - BF38 00A... three poles with RF...38 thermal overload relay BF26 00A...



Wiring diagrams



ENERGY AND AUTOMATION

MOTOR PROTECTION RELAY, PHASE FAILURE / SINGLE PHASE SENSITIVE. THREE POLE **electric** (THREE PHASE), MANUAL OR AUTOMATIC RESETTING. DIRECT MOUNTING ON BF09 - BF38 CONTACTORS, 1.6...2.5A

95 98 96

Certifications and compliance

Compliance

CSA C22.2 n° 14

IEC/EN 60947-1

IEC/EN 60947-4-1

UL508

Certifications

CCC

cULus

EAC