#### **Switching Power Supplies**

## PS5R-V



Space-saving DIN-rail switching power supplies.







• See website for details on approvals and standards.

#### Suitable for global and semiconductor applications

#### Meets SEMI F47 Sag Immunity

Voltage sag ride-through capabilities for semiconductor process equipment, metering equipment and automatic test equipment. (approved at 208V AC input)

	Part No.	Input Voltage	<b>Output Capacity</b>	Output Voltage / Output Current
750	PS5R-VB05		10W	5V/2.0A
TEN.	PS5R-VB12		15/4/	12V/1.3A
	PS5R-VB24	_	15W	24V/0.65A
	PS5R-VC12		30W	12V/2.5A
4204	PS5R-VC24		3000	24V/1.3A
100	PS5R-VD24	100 to 240V AC - (Voltage range: 85 to 264V AC / — 100 to 370V DC)	60W	24V/2.5A
60.	PS5R-VE24		90W	24V/3.75A
12A	PS5R-VF24		120W	24V/5.0A
240.	PS5R-VG24		240W	24V/10.0A

APEM Switches & Pilot Lights

Control Boxes

Emergency Stop Switches

Safety Products **Explosion Proof** 

Terminal Blocks

Relays & Sockets

Power Supplies

LED Illumination


Controllers Operator Interfaces Sensors

AUTO-ID

PS6R

Circuit Protectors

Enabling Switches





Volume:

Approx. 50% less\*2

Width:

Approx. **50**% less\*2



#### Reduced installation space

- · Required space between the switching power supplies reduced to half
- Size is reduced to the smaller output capacity (30W/90W/120W) \*1

#### Reduced wiring & flexible installation


- · Less wiring required
- Can be installed in six directions


#### Improved reliability

- Five-year warranty
- Operating temperature -25 to +75°C
- \*1 Compared with conventional PS5R-S model.
- \*2 Compared with conventional PS5R-S output capacity 30W model.

Conventional

#### Reduces installation space inside the panel





Slim size

Space between the switching supplies reduced to half


#### Reduced wiring & flexible installation

#### Reduced wiring



Spring-up terminals accepts wiring of ring terminals. No need to worry about loosing screws.

#### Six mounting directions



### **PS5R-V** Switching Power Supplies

### Space-saving DIN-rail switching power supplies

PS5R-V Package Quantity: 1

APEM
Switches & Pilot Lights
Control Boxes
Emergency
Stop Switches
Enabling

Safety Products

Switches

Explosion Proof
Terminal Blocks

Relays & Sockets

Circuit Protectors

Power Supplies

LED Illumination

Controllers

Operator

Interfaces Sensors

AUTO-ID

#### **End Clip**

240W

DIN Rail (35mm-wide)

PS5R-V
PS6R

Shape	10W/15W	30W	60W/90W	- 12	120W	240. 240W
Output Capacity	Part No.		Input Voltage		Output Voltage	Output Current
10W	PS5R-VB05				5V	2.0 A
15W	PS5R-VB12				12V	1.3 A
1300	PS5R-VB24				24V	0.65A
30W	PS5R-VC12		100 to 240V AC (Voltage range: 85 to 264V AC / 100 to 370V DC)		12V	2.5 A
3000	PS5R-VC24	(Voltage range:			24V	1.3 A
60W	PS5R-VD24	(voitage range.	00 to 2041 AO / 100 to 3/01 DO)		24V	2.5 A
90W	PS5R-VE24				24V	3.75A
120W	PS5R-VF24				24V	5.0 A

•	,				
Length	Part No.	Material	Weight	Package Quantity	Remarks
1,000mm	BAA1000PN10	Aluminum	200g	10	See H-071 for DIN rail products.
1,000111111	RAP1000PN10	Steel	320a	10	See H-071 for DIN rail products.

# Part No. Package Quantity Remarks BNL6PN10 10 Applicable rail: BAA,BAP Weight: approx.15g

PS5R-VG24


#### Panel Mounting Bracket \*1

Applicable Switching Power Supply	Ordering No.	Remarks
PS5R-VB	PS9Z-5R1B	_
PS5R-VC	PS9Z-5R2B	For side mounting
PS5R-VD PS5R-VE	PS9Z-5R1C	_
PS5R-VF	PS9Z-5R1E	_
PS5R-VG	PS9Z-6R1F	_
roon-Vu	PS9Z-6R2F	For side mounting

<sup>\*1:</sup> Used for direct panel mounting.

#### Part No. Development

24V



<sup>\*4:</sup> PS5R-VB only \*5: PS5R-VB/VC only

10.0 A

#### **Specifications**

<u> </u>	Part No.	)IIO	(10W/15W) PS5R-VB05 PS5R-VB12 PS5R-VB24	(30W) PS5R-VC12 PS5R-VC24	(60W) PS5R-VD24	(90W) PS5R-VE24	(120W) PS5R-VF24	(240W) PS5R-VG24
(5	ated Input Volta Single-phase two requency		100 to 240V AC (Voltage range: 85 to 264V AC 50/60 Hz	/100 to 370V DC) (Load ≤ 80%	at 100-105V DC)			
,	nput	100V AC	5V: 0.25A 12V, 24V: 0.35A	0.7A	1.3A	1.1A	1.4A	2.7A
	urrent (Typ.)	230V AC	5V: 0.14A	0.3A	0.8A	0.6A	0.7A	1.2A
F			12V, 24V: 0.19A	0.07	0.0.1	0.07		14A max.
	nrush	100V AC	18A (Ta = 25°C, cold start)					(Ta = 25°C, cold start)
	urrent (Typ.)	230V AC	45A (Ta = 25°C, cold start)					30A max. (Ta = 25°C, cold start)
	eakage	120V AC	0.5 mA max.					
L	urrent	230V AC	1.0 mA max.		ı	1		1
Efficiency 100V AC (Typ.)		100V AC	5V: 77%, 12V: 82%, 24V: 84%	12V: 83%, 24V: 85%	86%	88%		89%
	at rated utput) (*3)	230V AC	5V: 73%, 12V: 80%, 24V: 81%	12V: 85%, 24V: 87%	86%	89%		90%
Н	ower	100V AC	_	_	_	0.99		
	actor (Typ.)	230V AC	_	_	_	0.86	0.92	0.96
R	ated Voltage/Cu	rrent	5V/2.0A (*4), 12V/1.3A, 24V/0.65A	12V/2.5A, 24V/1.3A	24V/2.5A	24V/3.75A	24V/5A	24V/10A
A	djustable Voltag	e Range	±10%			±5%	±10%	
C	utput Holding ime (Typ.)	100V AC	5V: 53ms 12V: 34ms 24V: 36ms	12V: 13ms 24V: 15ms	13ms	20ms	30ms	30ms
(8	nt rated utput)	230V AC	5V: 330ms 12V: 215ms 24V: 230ms	12V: 110ms 24V: 110ms	105ms	30ms	33ms	40ms
	tart Time at rated input an	d output)	500 ms max.	600 ms max.	800 ms max.		700 ms max.	800 ms max.
Ř	ise Time	• •	5V, 12V: 200ms max. 200ms max.				I	I.
(6	Input Fluctuat		24V: 250ms max. 0.4% max.	200110 111211				
			5V: 2.5% max.	1.00/				
	Load Fluctuat	ION	12V, 24V: 1.0% max. 0.05%/°C max.	1.0% max. 12V: 0.05%/°C max. (-10 to +50°C)	I		I	
Ripple (including noise) (name transpersion of the control of the		Change	(-10 to +65°C) 5V: 8% p-p max. (-25 to -10°C)	24V: 0.05%/°C max. (-10 to +55°C) 12V: 6% p-p max. (-25 to -10°C)	0.05%/°C max. (-10 to +55°	0.05%/°C max. (-25 to +55°	C)	
			12V: 6% p-p max. (-25 to -10°C) 24V: 4% p-p max. (-25 to -10°C) 5V: 5% p-p max. (-10 to +0°C)	24V: 4% p-p max. (-25 to -10°C)	4% p-p max. (-25 to -10°C)		4% p-p max. (-25 to -10°C)	
		se)	12V: 2.5% p-p max. (-10 to +0°C) 24V: 1.5% p-p max. (-10 to +0°C) 5V: 2.5% p-p max. (0 to +65°C)	12V: 2.5% p-p max. (-10 to +0°C) 24V: 1.5% p-p max. (-10 to +0°C)	1.5% p-p max. (–10 to +0°C)		1.5% p-p max. (-10 to +0°C)	
	Overcurr		12V: 1.5% p-p max. (0 to +65°C) 24V: 1% p-p max. (0 to +65°C)	12V: 1.5% p-p max. (0 to +50°C) 24V: 1% p-p max. (0 to +55°C)	1% p-p max. (0 to +55°C)	I	1% p-p max. (0 to +55°C)	
uppl enta	D		105% min. (auto reset)			101% min. (auto reset)	105% min. (auto reset)	
nct	ions Operatio	n Indicator	LED (green)					
elec	tric Strength		Between input and output tern Between input and ground tern Between output and ground te	minals: 2,000V AC, 1 minute				
	tion Resistance			*	negger), Between input and gro	ound terminal: 100MΩ min. (50	OV DC megger)	
	ting Temperatur	e (*2)	-25 to +75°C (no freezing)	-25 to +70°C (no freezing)		-25 to +65°C (no freezing)		
	ting Humidity		20 to 90% RH (no condensation	n)				
	ge Temperature		-25 to +75°C (no freezing)	n)				
	age Humidity 20 to 90% RH (no condensation)  10 to 55 Hz, amplitude 0.375mm, 2 hours each in 3 axes (when used with part no. BNL6 mounting clips)  10 to 55 Hz, amplitude 0.33mm, 2 hours (when used with part no. BNL6 mounting clips)  10 to 55 Hz, amplitude 0.375mm, 2 hours (when used with part no. BNL8 mounting clips)		6 mounting clips) mm, 2 hours each in 3 axes	10 to 55 Hz, amplitude 0.21mm, 2 hours each in 3 axes (when used with part no. BNL6 mounting clips) 10 to 55 Hz, amplitude 0.375mm, 2 hours each in 3 axes (when used with part no. BNL8 mounting clips)	10 to 55 Hz, amplitude 0.375mm, 2 hours eacl in 3 axes (when used with part n BNL6 mounting clips)			
nock	Resistance		300 m/s², 3 times each in 6 di	rections	1		1 3. E. E. Mountaing Onipo)	
10		EMI	EN61204-3 (Class B)					
1C		EMS	EN61204-3 (industrial)					
UL508 (Listing), UL1310 Class 2, ANSI/ISA-12.12.01, CSA C22.2 EN60950-1, EN50178, SELV (UL60950-1, EN60950-1)			EN60950-1, EN50178, SELV (L	JL60950-1, EN60950-1)	2.2 No. 107.1, 213, 223		UL508 (Listing), ANSI/ISA-12.12 EN60950-1, EN50178, SELV (EN	
hor	Standard e of Protection		SEMI F47 (at 208V AC input or IP20 (EN60529)	y <i>)</i>				
_	o or i rotobubli				05H 20W 100D		115H × 46W × 121D	125H × 60W × 125D
gre	nsions (mm)	ensions (mm) 90H × 22.5W × 95D 95H × 36W × 108D						
egre	nsions (mm) nt (approx.)		90H × 22.5W × 95D 140g	150g	260g	310g	470g	960g

#### Reference Value

Expected Life (*5) 8 years minimum (at the rated input, 50% load, operating temperature +40°C, standard mounting direction)	Expected Life (*5)	8 years minimum (at the rated input, 50% load, operating temperature +40°C, standard mounting direction)
---	--------------------	--

<sup>\*5:</sup> Calculation of the expected life is based on the actual life of the aluminum electrolytic capacitor. The expected life depends on operating conditions.

Pilot Lights Control Boxes Emergency Stop Switches Enabling Switches Safety Products **Explosion Proof** Terminal Blocks Relays & Sockets Circuit Protectors

APEM Switches &

LED Illumination

Controllers Operator Interfaces

Sensors AUTO-ID

PS6R

At normal temperature and humidity unless otherwise specified.

\*1: DC input voltage is not subject to safety standards. When using on DC input, connect a fuse to the input terminal for DC input protection.

\*2: See the output derating curves on J-008.

\*3: Under stable state.

\*4: PSSR-VB05 (SV DC/2.0A) is 10W (Up to 3.0A at Ta = 0 to 40°C. Not subject to safety standards at 2.0A and over.)


Control Boxes

Emergency


Circuit Protectors

#### **Block Diagrams**


#### PS5R-VB



#### PS5R-VC/PS5R-VD




#### PS5R-VE24




#### PS5R-VF24





#### PS5R-VG24





J-007

APEM

Switches &

Pilot Lights

Emergency

Enabling Switches

Control Boxes

Stop Switches

Safety Products

**Explosion Proof** 

Terminal Blocks

Relays & Sockets

LED Illumination Controllers

Circuit

Protectors

Operator

Sensors

AUTO-ID


PS6R

#### **Characteristics**


#### Operating Temperature vs. Output Current (Derating Curves)

Conditions: Natural air cooling (Operating temperature is the temperature around the switching power supply.)


#### PS5R-VB05, -VB12, -VB24




#### PS5R-VC12




#### PS5R-VC24




PS5R-VD24




PS5R-VE24



PS5R-VF24



PS5R-VG24



Operating Temperature Approved by Safety Standards (°C)

Part No.	UL50	UL508, CSA C22.2 No.107.1, ANSI/ISA12.12.01, EN60950-1, EN50178				0178
rait NO.	Mounting A	Mounting B	Mounting C	Mounting D	Mounting E	Mounting F
PS5R-VB05, -VB12, -VB24	65	60	60	60	60	60
PS5R-VC12	50	45	45	45	45	45
PS5R-VC24	55	55	50	45	45	45
PS5R-VD24	55	40	40	40	45	35
PS5R-VE24	50	40	40	40	45	40
PS5R-VF24	55	40	45	40	45	35
PS5R-VG24	50	35	30	30	45	30

#### Mounting Style







(Left side up)



(Right side up)




(Upside down)



#### **Output Current vs. Input Voltage** (derating curves)

#### PS5R-VG24



APEM
Switches &
Pilot Lights

Control Boxes

Emergency
Stop Switches

Enabling Switches Safety Products

**Explosion Proof** 

Terminal Blocks

Relays & Sockets

Circuit

Protectors

LED Illumination


Controllers

Operator Interfaces Sensors


AUTO-ID

#### **Overcurrent Protection Characteristics**






### PS5R-VE24




#### PS5R-VG24



#### **Parts Description**


#### PS5R-VB/VC



#### PS5R-VD/VE/VF



#### PS5R-VG




PS5R-V PS6R


Marking	Name	Description
L, N	AC Input Terminal	Voltage range: 85 to 264V AC/100 to 370V DC
<b>(1)</b>	Ground Terminal	Be sure to connect this terminal to a proper ground.
+V, -V	DC Output Terminals	+V: Positive output terminal -V: Negative output terminal
VR.ADJ	Output Voltage Adjustment	Turning clockwise increases the output voltage. Turning counterclockwise decreases the output voltage.
DC ON	Operation Indicator (green)	Lights when the output voltage is on.

#### **Dimensions**


#### PS5R-VB/VC




PS5R-VD/VE



#### PS5R-VF



#### PS5R-VG



All dimensions in mm. Tolerance: ±1mm

APEM

Switches & Pilot Lights

Control Boxes

Emergency Stop Switches

Enabling Switches

Safety Products

**Explosion Proof** 

Terminal Blocks

Relays & Sockets

Circuit Protectors

LED Illumination

Controllers Operator

Interfaces

Sensors

AUTO-ID

PS6R

APEM

Switches & Pilot Lights

Control Boxes Emergency

Stop Switches

Terminal Blocks

Relays & Sockets

Controllers
Operator

Interfaces

Sensors

AUTO-ID

PS6R

Circuit Protectors

Enabling

Switches
Safety Products

#### **Dimensions**

#### **Panel Mounting Bracket** When installed on switching power supply PS9Z-5R1B 2-M4 or ø2-4.5 holes 120 Mounting hole layout when installing on a panel directly Front View Side View 24.7 PS9Z-5R2B Side-mount 2-M4 or ø2-4.5 holes 1 1 1 1 1 1 1 1 1 102 ၀ Mounting hole layout when installing on a panel directly Side View Front View PS9Z-5R1C 109.8 2-M4 or ø2-4.5 holes Mounting hole layout when installing on a panel directly Front View Side View PS9Z-5R1E 122.8 2-M4 or ø2-4.5 holes 135 Mounting hole layout when installing on a panel directly Front View Side View PS9Z-6R1F 130.6 4-M4 or ø4-4.5 holes 35 145 Mounting hole layout when installing on a panel directly 28 Side View Front View PS9Z-6R2F Side-mount 4-M4 or ø4-4.5 holes 62.3 999 138.6 148.6 38.6 ၀ All dimensions in mm. Mounting hole Tolerance: ±1mm layout for side mounting • Mounting Screws (4 M3×6 countersunk screws) Side View Back View

#### Safety Precautions

Mount the PS5R-V in an enclosure. Do not use the PS5R-V alone as an Electric Facilities for General Use.

Use the PS5R-V for electric facilities for business use only.

- Do not use switching power supplies with electric equipment whose malfunction or inadvertent operation may damage the human body or life directly.
- Make sure that the input voltage and output current do not exceed the ratings. If the input voltage and output current exceed the ratings, electric shock, fire, or malfunction may occur.
- Do not touch the terminals of the switching power supply while input voltage is applied, otherwise electric shock may occur.
- Provide the final product with protection against malfunction or damage that may be caused by malfunction of the switching power supply.

- Operating temperatures should not exceed the ratings. Be sure to note the derating characteristics. If the operating temperature exceeds the ratings, electric shock, fire, or malfunction may occur.
- Blown fuses indicate that the internal circuits are damaged. Contact IDEC for repair. Do not just replace the fuse and reoperate, otherwise electric shock, fire, or malfunction may occur.
- Do not use the switching power supplies to charge rechargeable batteries.
- Do not overload or short-circuit the switching power supply for a long period of time, otherwise the internal elements may be damaged.
- Do not disassemble, repair, or modify the power supplies, otherwise the high voltage internal part may cause electric shock, fire, or malfunction.
- The fuse inside the PS5R-V switching power supply is for AC input.
   Use a DC fuse for DC input.

3. Place the PS5R-V on the DIN rail as shown with input terminal side

4. Use BNL6 mounting clips for fastening the PS5R-V on the DIN rail.

vibration or shock is anticipated. Do not use the PS5R-V when it is

Use of BNL8 mounting clips is recommended when excessive

 Insert a flat screwdriver into the slot in the clamp, and pull out the clamp until it clicks (③). The lock mechanism is released and the

PS5R-V can be removed (4). When mounting the PS5R-V again,

Removal

up (1), and press the PS5R-V towards the DIN rail (2). Make sure

2. Fasten the DIN rail to a mounting plate using screws.

Mounting on DIN Rails

1. Use a 35mm-wide DIN rail.

that the PS5R-V is installed firmly.

subject to vibration constantly.

Mounting

push in the latch first.

Removal

#### APEM

Switches & Pilot Lights

Control Boxes

Emergency Stop Switches Enabling

Switches
Safety Products

\_\_\_\_\_

Explosion Proof
Terminal Blocks

Relays & Sockets

Circuit

Protectors

LED Illumination

Controllers

Operator Interfaces

Sensors

AUTO-ID


PS5R-V

PS6R

#### **Operating Instructions**

#### Notes for installation

- Do not close the top and bottom openings of the PS5R-V to allow for heat radiation by convection.
- Maintain a minimum of 10 mm clearance around the PS5R-V, except for the top and bottom openings.
- When mounting multiple PS5R-V switching power supplies side by side, maintain a minimum of 10 mm clearance. Observe the derating curves in consideration of the ambient temperature.



- When the derating voltage may exceed the recommended value, provide forced air-cooling.
- Make sure to wire the ground terminal correctly.
- For wiring, use wires of heat resistance of 60°C or higher (PS5R-VB: 80°C or higher). Use copper wire of the following sizes, according to the rated current.


Terminal	Wire Size (allowable current)	Wire Type
Input	AWG18 to 14	Copper
Output	AWG18 to 14 (AWG18: 7A, AWG16: 10A, AWG14: 15A)	Solid/Stranded

Cross-sectional area

AWG18: 0.82mm<sup>2</sup>, AWG16: 1.31mm<sup>2</sup>, AWG14: 2.0mm<sup>2</sup>

Note: Wires of the above size must be used to comply with UL508, CSA C22.2 No. 107.1.

#### Applicable crimp terminal (reference)



 $\bullet$  Recommended tightening torque of the input and output terminals is 1.0 to 1.3 N·m (0.8 N·m for UL).

#### **Operating Instructions**

#### **Installing the Panel Mounting Bracket**

#### <Installing PS9Z-5R1□ Panel Mounting Bracket>

APEM
Switches &
Pilot Lights

Control Boxes

Stop Switches
Enabling
Switches

Safety Products

Explosion Proof

Terminal Blocks

Relays & Sockets

Circuit Protectors

**Power Supplies** 

LED Illumination

Controllers


Operator Interfaces

Sensors


AUTO-ID

PS5R-V

PS6R



#### <Installing PS9Z-5R2B Panel Mounting Bracket>



① Pull out the latch to UNLOCK position.




② Insert the tab on the panel mounting bracket into the slot on the power supply

Ensure that the panel mounting

bracket is locked by the latch.




③ Push in the latch to LOCK position.



④ Ensure that the panel mounting bracket is locked by the latch.

## Installing PS9Z-6R2F Side-mount Panel Mounting Bracket

Install the bracket on the switching power supply using four M3  $\times$  6 countersunk screws supplied with the bracket.



#### **Adjustment of Output Voltage**

The output voltage can be adjusted within  $\pm 10\%$  of the rated output voltage (PS5R-VE:  $\pm 5\%$ ) by using the VR.ADJ control on the front. Turning the VR.ADJ clockwise increases the output voltage. Turning the VR.ADJ counterclockwise decreases the output voltage.

#### **Overcurrent Protection**

The output voltage drops automatically when an overcurrent flows due to an overload or short circuit. Normal voltage is automatically restored when the load returns to normal conditions.

#### Insulation/Dielectric Test

When performing an insulation/dielectric test, short-circuit the input (between L and N) and output (between +V and -V). Do not apply or interrupt the voltage quickly, otherwise surge voltages may be generated and the PS5R-V may be damaged.

#### **Notes for Operation**

• Output interruption may indicate blown fuses. Contact IDEC.

The PS5R-V switching power supply contains an internal fuse for AC input. When using with DC input, install an external fuse for DC input. To avoid blown fuses, select a fuse in consideration of the rated current of the internal fuse.

#### **Rated Current of Internal Fuses**

Part No.	Internal Fuse Rated Current
PS5R-VB/VC	2A
PS5R-VD/VE/VF	4A
PS5R-VG	6.3A

- Avoid overload and short-circuit for a long period of time, otherwise the internal elements may be damaged.
- DC input operation is not subject to safety standards.

#### Rust and Scratches on Metal parts

Hot-dip galvanized steel and bonderized steel are used for the PS5R-V. Rust on the edge and scratches on the surfaces may be developed depending on the storage condition, but the performance of the PS5R-V is not affected.


#### Noise

Small acoustic noise inside the PS5R-V may be heard depending on the input voltage and load, but the performance of the PS5R-V is not affected.

#### Operating Instructions

#### **Series Operation**

The following series operation is allowed. In (b) series operation, connect Schottky barrier diodes. Choose (a) series operation when using the PS5R-V as positive and negative output power supply. Insert a Shottky barrier diode for loads such as operational amplifier where outputs of two power supplies may be connected in series (Load 3). Select a Schottky diode in consideration of the rated current.




#### **Parallel Operation**

Parallel operation is not possible to increase the output capacity. because the internal elements and load may be damaged.

#### **Backup Operation**

Backup operation is a connection method of two switching power supplies in parallel for emergency. Normally one switching power supply has a sufficient output. If one switching power supply fails, another one operates to continue the output. Make sure that the sum of power consumption by load and diode is not greater than the rated wattage (rated voltage × rated current) of one switching power supply.



Select a diode in consideration of:

Diode's current must be more than double the PS5R-V's output current. Take heat dissipation into consideration.

IDEC shall not be liable for other damages including consequential,

1. Inappropriate handling, or operation beyond the specifications.

3. Failure caused by other than the PS5R-V switching power supply.

contingent or incidental damages. Warranty does not apply if the

PS5R-V switching power supply was subject to:

2. Modification or repair by other than IDEC.

4. Failure caused by natural disasters.

APEM

Switches &

Control Boxes

Emergency

Switches

Terminal Blocks

Relays & Sockets

Circuit

Controllers

Operator

AUTO-ID

Pilot Lights

Stop Switches Enabling

Safety Products

**Explosion Proof** 

Protectors

LED Illumination

Sensors

PS6R

#### Warranty

#### Warranty

IDEC warranties the PS5R-V switching power supplies for a period of five years from the date of shipment.

IDEC agrees to repair or replace the PS5R-V switching power supply if the product has been operated under the following conditions. The maximum value of output capacity is within the range shown in "Operating Temperature vs. Output Current" on J-008.

- 1. Average operating temperature (ambient temperature of switching power supply) is 40°C maximum.
- 2. The load is 80% maximum.
- 3. Input voltage is the rated input voltage.
- 4. Standard mounting style